



Angle Adjustable L Converter



Installation



- 1. F st, knock out the hole on the led wall pack light
- 2. Install the smart co erter into the knock down hole and fix it with nuts.
- 3. Connect the co esponding wires as shown in the document wiring diagram.
- 4. Install the Bluetooth module equired in the place of use into the converted jack interface.
- 5. Please disconnect all electrical connection



Angle Adjustable L Converter

Attention:

Precautions

- Turn the power off at the circuit breaker before installing the angle adjustable L converter.
- 2. This product installation requires handling 100-347volt wiring.
- 3. If any concerns handling wiring, hire a qualified electrician.
- 4. Ensure all work meets applicable local and national codes.



Important start-up information:

- We reserve the right to necessarily modify any incorrect words or pictures or technical parameters.
- Do not allow rework the Angle Adjustable L Converter without permission or authorization, otherwise the contract clauses quaranteed will be invalid immediately.
- 3. Contact TIOSL to get the detailed control setting guide.