ÉCLAIRAGE RENO® LIGHTING

DOUBLE RING VANITY SCONCE
INSTALLATION GUIDE

INSTRUCTIONS FOR THE FOLLOWING FIXTURES

ORDER#	MODEL#
R32019	RENO-AUREL-24-VLD-NL-BN


PLEASE READ CAREFULLY AND SAVE THESE INSTRUCTIONS, AS YOU MAY NEED THEM AT A LATER DATE.

CAUTION

1. TURN OFF ELECTRICAL POWER BEFORE STARTING INSTALLATION OF LIGHT FIXTURE.
2. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATIONCODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
3. **CAUTION, RISK OF FIRE.** CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

GENERAL

ALL ELECTRICAL CONNECTIONS MUST BE IN ACCORDANCE WITH LOCAL AND NATIONAL ELECTRICAL CODE (N.E.C.) STANDARDS. IF YOU ARE UNFAMILIAR WITH PROPER ELECTRICAL WIRING CONNECTIONS, PLEASE HIRE A QUALIFIED ELECTRICIAN. REMOVE THE FIXTURE AND ITS COMPONENTS FROM THE BOX AND MAKE SURE THAT NO PARTS ARE MISSING.




PACKAGE CONTENTS

Part	Description	Quantity
A	Fixture Housing	1
B	End Cap	2

HARDWARE INCLUDED

Part	Description	Quantity
AA	Mounting Plate (2-AA1)	1
BB	Electric Box Screw	2
CC	Drywall Anchor	3
DD	Mounting Screw	3
EE	Wire Connector	3



NOTE: This fixture should be used on a 120-Volt fused circuit only 60Hz.

WARNING: RISK OF ELE CTRIC SHOCK. Ensure the electricity to the wires you are working on is shut off. Either remove the fuse or turn off the circut break before removing and existing light fixture or installaing the new one.


If you are unfamiliar with electrical installations, we recommend you contact a qualified electrician to do the installation.

ÉCLAIRAGE RENO® LIGHTING

DOUBLE RING VANITY SCONCE
INSTALLATION GUIDE


INSTALLATION

1 Use two hands to slide the two side end caps (B) per the unlocking mark. Then use two hands to press the sides of the lens inward, in the direction shown to release it and lift it from the fixture housing (A).




2 Choose your favorite correlated color temperature (CCT) from five options: 2700K warm white, 3000K soft white, 3500K neutral white, 4000K cool white, or 5000K daylight. Move the toggle switch on the fixture body (A) to make your selection before inserting into bracket or ceiling.

NOTE: The factory set ting for the correlated color temperature (CCT) is 3000K, which is the warmest white light.



2700K/3000K/3500K/4000K/5000K




3 Using a screwdriver, punch out the knock out holes and keyholes in the fixture housing (A) for wiring and fixture mounting.

4 Mounting plate(AA) is marked on the J-Box. Drill a 1/8-in.(BB) pilot hole into the screw locations Temporarily hold the fixture housing (A) up to the ceiling to determine the best mounting position. Mark two keyhole locations on the mounting surface.

You can also use an awl or nail to dimple the screw holes. Install a dry wall anchor (CC) in each drilled mounting hole, but do not tighten fully.

The dry Wall Anchors (CC) are only to be used for mounting the fixture to plaster or drywall surfaces



905-604-4666 | info@renolighting.com | www.renolighting.com


ÉCLAIRAGE RENO® LIGHTING

DOUBLE RING VANITY SCONCE
INSTALLATION GUIDE

5 Feed the electrical wires from the electrical box through the open knock out hole。


Make the electrical connections:

- Black wire to black wire.
- White wire to white wire.
- Ground wire to ground.
- Use wire connectors(EE) to cover the wire connections and wrap with electrical tape.




6 Tuck wires inside the electrical box and snap electrical box cover to the electrical box. Mount the fixture housing (A) to Mounting plate(AA) using the two Nut screws (AA-1).


Align the mounting keyholes on the fixture housing (A) with the mounting screws (DD) in the ceiling. Once the screw heads are through the large ends of the keyholes, slide the housing (A) until the heads of the mounting screws (DD) slide into the narrow ends of the keyholes. Finish tightening the mounting screws (DD) until the fixture housing (A) is tightly secured to the mounting surface.




7 Reattach the lens into the fixture housing (A) as shown.



8 Slide both side end caps (B) into the fixture. Ensure to have the rims of the end caps (B) in between the slot of the fixture and hear click sounds after locking successfully.



9 Restore the power supply to turn on the light.



NightLight

To switch between the area light and 2000K nightlightmodes, flip the wall switch On/Off/On within three seconds.

