

Date	Project	
Туре	Part Number	



ALL-IN-ONE PERFORMANCE LIGHTING

# **T8** Series

# 4ft Bypass Ballast LED T8 Tube

Ballast Bypass T8 Tubes are designed for direct wiring, eliminating the need for a ballast. These energy-efficient bulbs offer superior brightness, long-lasting performance, and easy installation. Ideal for retrofit projects, they reduce maintenance and energy costs while providing flicker-free, high-quality illumination.



### **PRODUCT FEATURES**

- Built-in safety switch prevents electrical shock during installation
- Operates directly on 120-277V & 347V line voltage
- Compatible with shunted and non-shunted lamp holders
- Rated for use in fully enclosed fixtures.
- Suitable for use in dry and damp locations
- NSF Listed: NSF/ANSI Standard 2 Food Equipment
- Operating Temperature: -4°F to 113°F (-20°C to 45°C)
- 120V TRIAC Dimming
- Reno LED T8 lamps conform to UL 1598 Standard
- 10 year limited warranty

### **KEY SPECIFICATIONS**

Voltage	120-347V	
Lamp Base	G13 (Medium Bi-Pin)	
Wattage	10.5W	
Length	4FT	
Efficacy	Up to 171 lm/W	
ССТ	<b>Selectable CCT</b> : 30/35/40/50/6500K	
CRI	>83	
CRI Lumens	>83 Up to 1,800 lm	
Lumens	Up to 1,800 lm	
Lumens Beam Angle	Up to 1,800 lm 330°  Double ended or Single ended power (347V only	









## **SPECIFICATIONS - T8 TYPE B**

Order#	Model	Wattage	Voltage	Lumens	Efficacy	ССТ
R42126	RENO-LEDT8BP-10.5W-MCCT-48G	10.5W	120-347V	1,650 lm	157 lm/W	3000K
				1,650 lm	157 lm/W	3500K
				1,700 lm	162 lm/W	4000K
				1,800 lm	171 lm/W	5000K
				1,700 lm	162 lm/W	6500K

## **DLC CERTIFICATION**

Order#	Model	Application	DLC Standard	DLC Premium
R42126	RENO-LEDT8BP-10.5W-MCCT-48G	Internal Driver/Line Voltage (UL Type B) Lamps	S-VNYQ4P	-

## **ACCESSORIES**



RENO-S-SN-U-PBT


Shunted T8 Socket

Model	Description
RENO-S-SN-U-PBT	Shunted T8 Socket





## **DIMENSIONS**









#### PROTECTION FEATURES

#### **INTERNAL SAFETY SWITCH**



Internal Safety Switch for installation protection. (No current will flow until pins on both ends are engaged)

#### MISUSE PROTECTED FUNCTION



Misuse - Protected function if forgot to by-pass the ballast, the lamp won't work, no risk of fire or cap melting.

### **DOUBLE-ENDED INSTALLATION**

- 1. Cut all existing connections to ballast as shown below and remove ballast. See Figure A above for typical ballast configurations.
- 2. Re-wire fixture as shown below. For Double-ended wiring, use either shunted or nonshunted lampholders. **Note:** There should not be any exposed wires at the end of installation.

